

Wind Indicator

風向風速計

Receiver

受信器

| TYPE(形 式) | A | B | C | D | E |
|-----------------|-----|-----|-----|-----|-----|
| FL150SEL、FE150S | 150 | 183 | 160 | 200 | 162 |
| FL200SEL、FE200S | 200 | 232 | 210 | 250 | 212 |

FL : with illumination

FE : without illumination

