


Wind Indicator

風向風速計

FL130EL/FE130

風向計




Receiver


受信器

FL : with illumination

FE : without illumination






PANEL CUT



取付穴



風速計




取付穴

FL100EL/FE100

風向計





PANEL CUT




取付穴

風速計



4-φ6 BOLT HOLES

取付穴



4-φ6 BOLT HOLES

取付穴